



LAGERUNG VON HANDLÄUFEN

Eine fachgerechte Lagerung von Semperit Handläufen dient dem Qualitätserhalt der Produkte.

Normgerechte Lagerung*

Die Lagerung von Handläufen hat

- kühl und trocken,
- vor Licht und Verunreinigungen geschützt
- und bei Temperaturen von +5° C bis +25° C zu erfolgen.

Unzulässige Belastungen durch schwere Teile sind untersagt (Stapelhöhe Handläufe max. 80cm). Stapeln Sie niemals mehr als 2 Handläufe übereinander und keine Paletten auf Handlaufkartons.

| | Lagerung ab Prüfdatum | Zusatzinfo |
|-------------------|--------------------------|--|
| Endloser Handlauf | ≤4 Monate >4 Monate | In Originalverpackung HL auspacken und ohne Knickung lagern |
| HL rohes Ende | ≤3 Monate | In Originalverpackung |
| HL auf Trommel | ≤12 Monate >12 Monate | Die HL Maße können sich auf Werte leicht außerhalb der Toleranz ändern. Dies hat keinen Einfluss auf die Betriebszuverlässigkeit. Deckplattenalterung und Dimensionsänderungen können einen Einfluss auf die Betriebszuverlässigkeit haben. |

Wichtiger Hinweis

Die Gesamtlagerzeit von 12 Monaten ab Prüfdatum darf bei vulkanisierten Handläufen nicht überschritten werden. Bei Überschreitung der empfohlenen Lagerzeit oder Nichteinhaltung der Lagerbedingungen erlischt jeglicher Anspruch auf Gewährleistung oder Haftung.

* DIN 7716/82, ISO 2230:2002 + 5285:2004 + 7664:2000

All specifications, numbers, calculations, test values, and data mentioned here – which are the basis for our customer consultation – are in accordance with the latest engineering standards. As the operating conditions have an influence on product application, it is the sole responsibility of the customer to check the application conditions of each individual case, and whether the specified quality criteria of our products are adequate for the intended purpose. Improper use, excessive loading, or exposure to impermissible media can impair the product's function. The pictures and graphics shown are only representative images. No liability is accepted for mistakes or printing errors, and data is subject to change at any time. Copying and distribution in any form whatsoever, in whole or in part, only with the express written consent of Semperit. © Copyright 2022 Semperit Technische Produkte GmbH. All rights reserved.

SEMPERIT 

Semperit Technische Produkte Gesellschaft m.b.H.
 Triester Bundesstraße 26, 2632 Wimpassing, Austria
 ☎ +43 2630 310-0
 📠 +43 2630 310 288
 ✉ handrail.emea@semperitgroup.com
 🌐 www.semperitgroup.com



FIND OUT MORE